



Arzel Zoning Technology

AirBoss® Panel Wiring




Rheem Contour W/2nd Stg Ht Relay

All zones will be served heat at the requested capacity (V signal) of zone 1 Contour T-stat

If zone 1 is satisfied (or calling for minimal 40% capacity), a heating call from zones 2,3 or 4 will operate furnace at 40%.

A call for 2nd stg heat (W2) from zones 2,3, or 4 will open the "V" signal relay contacts and ramp output to 100% capacity.



Where Comfort is Guaranteed

216-831-6068 / Fax 216-831-6074

National Tech Support Hot Line 1-800-611-8312

www.arzelzoning.com



Arzel Zoning Technology

AirBoss® Panel Wiring




Rheem Contour W/ "V" signal direct to Furnace

All zones will be served heat at the requested capacity (V signal) of zone 1 Contour T-stat

If zone 1 is satisfied (or calling for minimal 40% capacity), a heating call from zones 2,3 or 4 will operate furnace at 40%.

Refer to the "Contour w/2nd stg Relay" diagram if 100% capacity is required when zone 2, 3 or 4 call for W2



Where Comfort is Guaranteed

216-831-6068 / Fax 216-831-6074

National Tech Support Hot Line 1-800-611-8312

www.arzelzoning.com