


# Arzel Zoning Technology, Inc.

## AirBoss Diagram

*ZVI Board to control Hydronic Heat w/ 2 stg HP used as Back-Up*

With the Thermostat in the Emerg Ht mode  
it will use Hydronic Heat to serve the zones

With the Thermostat in the Normal Heat mode  
it will use the Heat Pump serve the zones



Technical Support Hot-Line 1-800-611-8312  
www.arzelzoning.com